



UNITS 5&6 BOWLES WELL GARDENS – FOLKESTONE – KENT – CT19 6PQ
TEL: 01303 245300 – FAX: 01303 240666 – WEB: WWW.PIPEREXHAUSTS.CO.UK

Lotus Elan – Exhaust fitting guide.

Notes:

- Ensure you have new nuts to join the system to the pre cat. These need to be purchased from Lotus. Your old ones may be re used if they are still in good condition.
- This fitting guide is detailed with the standard system already been removed.

Instruction.

- 1) Ensure you have all the correct parts to your system and fitting kit.

- Flexi section
- Front section
- Centre section
- Rear section
- 4 Rubbers
- 1 Mikalor Clamp
- 1 U-Clamp
- Ring Seal
- Gasket
- 2 Bolts

Picture.



- 2) Make sure you have all the correct tools. We suggest:

- 10mm and 17mm Sockets
- Ratchet
- 13mm and 17mm Spanners
- WD40
- A Jack
- A rubber pulling hook



- 3) Clean the gasket face of the pre cat.



- 4) With the aid of WD40 place all the rubbers on the hooks.



- 5) Fit front section of new exhaust and hang onto the rubber.



- 6) Place on clamp (Mikalor style) to the end of the front section.



- 7) Slip on centre section into the front section. Do not hang on rubbers yet and do not tighten the clamp.



- 8) Jack up the car in front of the off side rear wheel at jacking point.



- 9) Place on clamp (U-Style) to end of centre section.



- 10) Guide rear section onto centre section at a 90 degree angle as shown. Do not do up clamp yet.



- 11) Then rotate box through 90 degrees to get the silencer level.

