











See 43-05A



See 17-06A



ELAN
42-05A



FUNCTION CODE	CONTENTS: Fuel Injection System		QUANTITY		REMARKS
			TURBO	N.A.	
42.05A	PART DESCRIPTION	PART NUMBER			
1	Injector Rail Assembly	A100L6026S	1		
1a	Injector Rail Assembly	A100L6025S		1	
1b	Fuel Rail, bare	A100E6571S	1		
1c	Fuel Injector	A100E6574S	4		
1d	Gasket, fuel injector	A100E6575S	8		
1e	Clip, fuel injector	A100E6576S	4		
1f	Pressure Regulating Valve (P.R. V.)	A100E6572S	1		
1g	Seal Set, fuel rail	A100E6573S	1		
2	Bolt, fuel rail fixing	A100L6027S	2	2	
3	Pipe, fuel feed	A100L6028S	1	1	
4	Clip, fuel feed pipe	A100L6030S	1	1	
5	Clip, fuel feed hose	A100L6032S	1	1	
6	Pipe, fuel return	A100L6029S	1	1	
7	Bolt, fuel pipe fixing	A100L6327S	3	3	
10	Sensor, manifold air temperature (M.A.T.)	A100L6283S	1	1	
11	Hose, pressure regulating valve to plenum	A100L6033S	1	1	
12	Clip, pressure regulating valve to hose	A100L6036S	2	2	